

P10HK-1 Polystyrene Deep Hive Kit with 1 Box



P10HK-1 Polystyrene Deep Hive Kit with 1 Box



Assemble your box first.

Take the two short box ends, and slide the top and bottom rails into place as shown in the photo at left.

Once you have the rails in place, you can begin assembling your hive box. Take your 2 longer box sides, lay one face down, place glue* on the pegs of the short sides, slide the short end pegs into the long side holes. Place glue* on the remaining 2 pegs and place them into the holes of the remaining board. Your box is now assembled.



*Suggested Glue: Tite-Bond I or III or Wood Glue

Slide in your Varroa Screen. Be sure to slide it in under the built in pegs to hold it in place.



Slide the bottom board into place as shown below. It will sit under the Voroa Screen.





** Paint all surfaces that will be exposed to UV light. Suggested paint: floor or cement paint



