

## Installation with Ultimate IPM Bottom Board™

- Installation is best done at night or early morning while bees are in hive, unless robbing is taking place, then install without delay.
- Pull out **Push Pins** from top. Save or discard protective foam.
- Place Ultimate Universal Robbing Screen on landing board, making sure that the alignment pins on bottom engage the holes in Ultimate IPM Bottom Board.
- Install single **Push Pin** in hole on top flange to attach.
- Install optional **Push Pins** on side flanges for stronger attachment.
- Installation is the same for 10-frame and 8-frame hives.

## Installation with Conventional Bottom Boards

- 10-FRAME HIVES
- Installation is best done at night or early morning while bees are in hive, unless robbing is taking place, then install without delay.

- Pull out **Push Pins** from top. Save or discard protective foam.
- Place **Ultimate Universal Robbing Screen** on landing board, the pins on the bottom act as a lower vent that is bee proof.
- Install **Push Pins** in the center hole on top and on each side flange to attach.
- 8-FRAME HIVES
  - Installation is best done at night or early morning while bees are in hive, unless robbing is taking place, then install without delay.
    - Pull out **Push Pins** from top. Save or discard protective foam.
    - Using the edge of a hive tool or knife score the V-grooves in the side wings and break off.
    - Place **Ultimate Universal Robbing Screen** on landing board, the pins on the bottom act as a lower vent that is bee proof.
    - Install **Push Pins** in the center hole on top and on each side flange to attach.

## Using the Ultimate Universal IPM Robbing Screen™

- Installation is best done at night or early morning while bees are in hive, unless robbing is taking place, then install without delay.
- Open 1 of the swinging doors, lifting gently, and rotate to the full open position.
- If robbers find their way in switch to the other door at night.
- SPRING: It is best to install your Robbing Screen early

in the season when starting Spring feeding and then remove once nectar flow starts.

- **SUMMER:** It is best to install your **Robbing Screen** after the nectar flow stops or if you have taken honey and keep it on until Fall feeding is completed.
- FALL: Leave Robbing Screen on until late fall and then install mouse guard.

## **Bee Smart Designs**

195 Atlantic Avenue • Garden City Park, New York 11040 (Toll Free) 800-600-7446 • (Phone) 516 741-3062 • (Fax) 516 742-3617 info@beesmartdesigns.com • www.beesmartdesigns.com